

Installation of Fuse

ColoQuick

Pasteur Basic2



Step 1: Tools Needed

Items: needle nose pliers, fuse holder, 3amp fuse



Step 2: Identify wire

Far right (white) wire on drive motor



Step 3: Cut wire

Use wire cutters to cut wire for fuse holder



Step 4: Separate wire



Step 5: Insert fuse holder

Put ends of wire into the holes in holder



Step 6: Close clamp

Ensure that wire is fully inserted upon clamping



Step 7: Clamping wire

Use a pliers to fully engage the clamp on wire



Step 8: Confirm

Make sure that clamps are fully closed



Step 9: Fuse

Use a 3amp car fuse



Step 10: Insert fuse

Insert 3amp car fuse in slot