

<b>Installation of inlet valve</b>	ColoQuick	MAXX4, MAXX8		



**Step 1: Tools and supplies**  
 Items: crescent/pipe wrench, screw driver, Allen wrench, new valve, plumbers tape



**Step 2: Prepping unit**  
 Shut off water to unit. Unplumb unit from supply. Remove back panel



**Step 3: Unplug connector**  
 Remove the screw in the top of the connector and unplug it.



**Step 4: Unhook clamps**  
 Unhook the mounting clamps



**Step 5: Unhook coupler**  
 Unhook the pipe coupler and remove the plumbing assembly



**Step 6: Remove valve**  
 Remove the bad solenoid valve from the plumbing assembly



**Step 7: Install new valve**  
 Install the new valve to the plumbing assembly.



**Step 8: Reassembly**  
 Reconnect the pipe coupler and mounting clamps. Plug the electrical back in and tighten the screw in the top.

**Step 9: Hook back up**  
 Plumb supply back in and turn water back on. Then reinstall back panel.